




IBM Thinkpad T61 Hard Drive Replacement

How to replace the harddrive.

Written By: Kyle






TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Hard Drive



- Turn the computer over so that the back is facing upwards.
- Locate the screw in the bottom left-hand corner of the computer.

Step 2



- Using a #0 Phillips screwdriver, remove the 17 mm screw.

Step 3



- Carefully remove the plastic piece covering the hard drive by first pulling up then away from the computer.

Step 4




- Locate the folded black tab within the hard drive port.
- With a screwdriver, pull the black tab out of the slot.

Step 5



- Pull gently on the black tab and the metal tray holding the hard drive will slide out.

Step 6



- Remove the plastic coverings on both sides of the hard drive.
- ⓘ Note that there is no hard drive in this picture but the process will remain the same.

To reassemble your device, follow these instructions in reverse order.

